



## **Installation Instructions for Rear brake adapters (drum brake hard lines to disc brake soft lines) :**

Parts included :

- Adapter fittings (pair)

- 1) Unbolt the hard lines from the rear drum wheel cylinders (if not done already).
- 2) Ford uses a smaller brake line size on the drum brake hard lines than they do with the disc brake cars. Thus to use the caliper soft lines from these cars, you need to adapt.
- 3) Once you are ready to install the adapter fittings, put them in the caliper soft lines first!
- 4) You will notice that you have a bit of extra hard line, There are 3 ways to deal with it:
  1. Coil the line up using a tubing bender or 1" sized socket
  2. Cut the line shorter and re-flare the hard line to the correct length. Keep in mind you need to double flare
  3. Remove the axle bracket from the soft line and gently bend the hard line to mate up with the caliper soft line
- 5) Once you have the hard line positioned to mate with the soft line, connect the hard line into the soft line.

### **Important Notice!**

#### **No Parts Warranty**

These parts are for competition use only. Competition parts are sold "as-is" without any warranty whatsoever. Mustang Brakes Parts and Matt90GT hereby disclaims and excludes any and all Express or Implied warranties, including warranties of merchantability and fitness for a particular purpose. The entire risk as to the quality and performance of these parts is with the buyer. Should any parts prove defective following their purchase, the buyer and not the manufacturer, distributor, or retailer, assumes the entire cost of all necessary servicing or repair. Mustang Brake Parts nor Matt90GT shall not be liable for damages or injury to persons or property resulting from the use of these parts! All Parts are sold as-is with no returns accepted.